PRIME SERIES UPRIGHT ASSEMBLY



STEP 1

From the rear side of the workstation, slide the upright mounting bracket forward until the two bracket holes align with the corresponding mounting holes in the top.



STEP 2

Insert the mounting bolts with flat washers through the top.



STEP 3

From underneath the frame, install a flat washer, lock washer, and nut onto each bolt. Once all hardware is properly aligned, tighten securely without over-torquing.