PRO SERIES ADJUSTABLE FOOTREST INSTALLATION



STEP 1

Position the footrest at the desired location on the workstation frame.



STEP 2

Insert the mounting bolt through the footrest bracket and frame tube.



STEP 3

Install and hand-tighten the adjustment knob until the footrest is securely locked in place.